


## *All Brandons Include the Rated Load Limiter*



*Identifies the Attachment Installed*

*Identifies the Current Load*

*Identifies the Capacity at Current Position*

**STOPS WHEN CAPACITY IS REACHED**